

ORDER NOW AT HUYETT.COM!





Chain & Chain Hardware • Clevises • Eye Bolts • Hoist Rings • Hooks
Lifting Eye Bolts • Lifting Eye Nuts • Nut Eye Bolts • Rod Ends • Screw Eye Bolts
Shackles • Swivels • Turnbuckles • Wire Rope Hardware • Yoke Ends


Search our full line of Premium Lifting Hardware or download a catalog or today at huyett.com.



BENT WIRE EYE BOLTS

TURNED






Design:	Bent Wire
Process:	Turned
Threads:	RH/UNC
Material:	Low Carbon Steel
Finish:	Zinc Clear Trivalent
Nut:	Hex

ITEM NUMBER	SHANK DIAMETER (A)	SHANK LENGTH (B)	ID EYE (C)	OVERALL LENGTH (D)	THREAD LENGTH (T)	WORKING LOAD LIMIT	WEIGHT/PC. (Approx.)
BWT025-20-100-087ZP	1/4"	1"	1/2"	2"	7/8"	74 lbs.	.04 lbs.
BWT025-20-150-125ZP	1/4"	1-1/2"	1/2"	2-1/2"	1-1/4"	74 lbs.	.04 lbs.
BWT025-20-200-125ZP	1/4"	2"	1/2"	3"	1-1/4"	74 lbs.	.05 lbs.
BWT025-20-400-250ZP	1/4"	4"	1/2"	5"	2-1/2"	74 lbs.	.08 lbs.
BWT025-20-600-400ZP	1/4"	6"	1/2"	7"	4"	74 lbs.	.09 lbs.
BWT031-18-200-125ZP	5/16"	2"	5/8"	3-1/8"	1-1/4"	74 lbs.	.09 lbs.
BWT038-16-100-087ZP	3/8"	1"	3/4"	2-1/2"	7/8"	144 lbs.	.12 lbs.
BWT038-16-150-113ZP	3/8"	1-1/2"	3/4"	3"	1-1/8"	144 lbs.	.13 lbs.
BWT038-16-200-125ZP	3/8"	2"	3/4"	3-1/2"	1-1/4"	144 lbs.	.15 lbs.
BWT038-16-300-150ZP	3/8"	3"	3/4"	4-1/2"	1-1/2"	144 lbs.	.17 lbs.
BWT038-16-400-250ZP	3/8"	4"	3/4"	5-1/2"	2-1/2"	144 lbs.	.21 lbs.
BWT038-16-600-400ZP	3/8"	6"	3/4"	7-1/2"	4"	144 lbs.	.24 lbs.
BWT050-13-200-150ZP	1/2"	2"	1"	4"	1-1/2"	298 lbs.	.33 lbs.
BWT050-13-400-250ZP	1/2"	4"	1"	6"	2-1/2"	298 lbs.	.41 lbs.
BWT050-13-600-400ZP	1/2"	6"	1"	8"	4"	298 lbs.	.50 lbs.

Additional finishes available. Contact our friendly Sales Team for more information.

PROPER INSTALLATION AND USE OF BENT WIRE EYE BOLTS



Bent Wire Eye Bolts are intended for use with static loads only. Do Not Exceed Weight Load Limits!

To prevent stretching, bending, or twisting that may result in the eye opening, never use bent wire eye bolts for pulling, lifting, or towing.

Safety Precautions:

- Do not open the eye and bend back. This will weaken the eye bolt.
- Do not use eye bolts that have been machined or ground down.
- Do not use wrenches, bars, or grips to tighten eye bolts.
- Do not paint an eye bolt. Paint can cover up flaws.
- Do not force hooks or other fittings into the eye, they must fit freely.
- Do not shock load eye bolts.
 The increased force can cause system failure.
- Do not use eye bolts that have signs of wear or quality issues.

